

# BRIC-Link II

## Installation Guide Rack Shelf Assembly

### Installing Front Bracket

---

- 1) Remove the front panel from the end of the BRIC-Link II case by removing the 4 - #4-40 x 3/8" black screws and headphone jack nut. Remove the 4 rubber feet on the bottom of the BRIC-Link II.
- 2) Orient and fasten the case to the rack shelf panel using the 4 - #4-40 x 3/8" black screws and headphone jack nut. Make sure the case and cover are flush to the rack shelf panel.
- 3) Repeat this process for the second BRIC-Link II case.
- 4) If you are not installing a second BRIC-Link II to the rack shelf panel a blank plate is available to cover the second set of cutouts.
- 5) To install the blank plate, place it over the appropriate holes in the rack shelf panel and fasten it with 4 - #4-40 x 3/8" black screws and 4 - #4-40 x 1/4" keps nuts.
- 6) Place the case and rack shelf panel assembly on the rack shelf, aligning the rack mounting holes at each side.
- 7) Slide everything into your rack and fasten it with the rack manufacturer's suggested hardware.
- 8) Plug the power supply/supplies into the BRIC-Link II(s) and then your audio and Ethernet cables.

